



## CHARGING YOUR POWER BANK


Before first use, ensure the power bank is fully charged to maximize its battery lifespan.

Connect the X Blade 5K to any USB power supply using the included USB Type-C cable.

Once charging begins, LED2 to LED4 will flash, depending on the current battery level. When fully charged, LED2 to LED4 will remain solid green.

## WIRELESS CHARGING

Place your phone or any wireless charging-compatible device on the magnetic surface as shown in the picture. Once wireless charging begins, a charging animation will appear on your phone's screen, and LED1 will turn green.



## WIRED CHARGING

Connect your device using a USB cable via the X Blade 5K's USB Type-C port.

## NOTE

Both wireless and wired charging should begin automatically when the device is connected. In rare cases, you can manually start charging by pressing the power button on the X Blade 5K.

● LIGHT ON	● LIGHT OFF
● ● ● ● ●	● ● ● ● ●
● ● ● ● ●	● ● ● ● ●
● ● ● ● ●	● ● ● ● ●
● ● ● ● ●	● ● ● ● ●
● ● ● ● ●	● ● ● ● ●

**Wireless Charging Starts**

- 0% - 25%
- 25% - 50%
- 50% - 75%
- 75% - 100%

## FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## FCC Radiation Exposure Statement

This device has been evaluated to meet general RF exposure requirements. It can be used in portable exposure conditions without restriction. This device complies with Part 15 of the FCC Rules. Operation is subject to

the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

**Note:** The magnetic function only adjusts the charging position.

## Important Safety Instructions:

- Store the power bank in a cool, dry place.
- Do not store the power bank in hot or humid environments.
- The operating temperature should be between -10°C and 45°C.
- If the power bank is not used for extended periods, charge and discharge it once every three months.
- When charging a device, the power bank may feel warm; this is normal and not a cause for concern.
- Under normal conditions, battery performance will decline over several years.
- Do not dispose of the power bank in heat or fire.
- Avoid cleaning the power bank with harmful chemicals or detergents.
- Misuse, dropping, or excessive force may cause damage to the product.



This symbol indicates that the product should not be disposed of as household waste. Instead, it should be taken to an appropriate collection point for the recycling of electrical and electronic equipment.